

SNAPBAG[®] for ARRI[®] SKYPANEL[®] X21

Please also refer to the luminaire instructions regarding use of accessories.

L2.0049580 / SBA21X



SAFETY INSTRUCTIONS



dopchoice.com/instructions

Open the SNAPBAG and align it with the safety loop facing up.

Place the white elastic wires around the X21 corners. Tighten them. Don't cover the heat vents on the sides and back.

SNAPBAG® for ARRI® SKYPANEL® X21

Please also refer to the luminaire instructions regarding use of accessories.

L2.0049580 / SBA21X



Pull the rubber bands over the dome hooks. And secure the SNAPBAG with the elastic loop.



MOUNTING POINT FOR THE SAFETY CABLE

Always secure the accessory with a suitable safety cable from falling when the primary mounting method fails.



Insert the front diffusion

**Read also our additional safety & handling instructions:
www.dopchoice.com/instructions**