

SNAPBAG[®] for LITEPANELS[®] ASTRA 1x1

#900-0032



- 1) Open the SNAPBAG[®],
2 Elastics face to left and right.
-



- 2) Pull the 2 Elastics over the
Knobs on the left and right side.
-



- 3) Pull the Elastics on all 4 corners
over the housing
-



SNAPBAG[®] for LITEPANELS[®] ASTRA 1x1

#900-0032



4) All 4 Elastics are now pulled over the corners of the Astra housing.



5) Inside: The SNAPBAG[®] is mounted with the corner webbing.



6) Insert diffusion

