SNAPGRID® for ARRI® SKYPANEL® X21

Please also refer to the luminaire instructions regarding use of accessories. L2.0049582 / SGA21XP30





Open the SNAPGRID and align it with the safety loop facing up.

Place the white elastic wires around the X21 corners. Tighten them. Don't cover the heat vents on the sides and back.

SNAPGRID® for ARRI® SKYPANEL® X21

Please also refer to the luminaire instructions regarding use of accessories. L2.0049582 / SGA21XP30



Pull the rubber bands over the dome hooks. And secure the SNAPGRID with the elastic loop.

MOUNTING POINT FOR THE SAFETY CABLE Always secure the accessory with a suitable safety cable from falling when the primary mounting method fails.



Read also our additional safety & handling instructions: www.dopchoice.com/instructions

