

SNAPBOX[®] SNOOT for ARRI[®] SKYPANEL[®] X21

Please also refer to the luminaire instructions regarding use of accessories.

L2.0049585 / SXA21X



Open the SNAPBOX and align it with the safety loop facing up.



Place the white elastic wires around the X21 corners. Tighten them. Don't cover the heat vents on the sides and back.



SAFETY INSTRUCTIONS



dopchoice.com/instructions

SNAPBOX[®] SNOOT for ARRI[®] SKYPANEL[®] X21

Please also refer to the luminaire instructions regarding use of accessories.

L2.0049585 / SXA21X



Pull the rubber bands over the dome hooks. And secure the SNAPBOX with the elastic loop.



MOUNTING POINT FOR THE SAFETY CABLE

Always secure the accessory with a suitable safety cable from falling when the primary mounting method fails.



Read also our additional safety & handling instructions:
www.dopchoice.com/instructions